



Zee Base Installation Instructions

Zee base is used with lockers without legs. It is used where continuous base is needed. It is used instead of concrete or wood bases.

Zee base comes in 4" or 6" heights and is 72" long; installer must cut in the field when shorter length is needed.

For longer runs, two or more pieces of zee base can be joined together with splice/ends.



- 1) Cut zee base to proper length and bolt together for needed locker run.
- 2) Bolt splice/ends on zee base (splice ends are roughly 2" shorter than matching locker).
- 3) Use the two set of holes on the splice/ends to attach two pieces of zee base together.
- 4) Splice/ends and zee base are turn up so the bottom flange with the holes for the anchor is flat on the floor.
- 5) With zee base bolted together butt zee base splice ends tight against the wall; zee base towards the front and splice/ends against the wall.
- 6) Anchor zee base to floor with ¼" anchors using holes in the bottom of the zee base.
- 7) Place and stich together assembled lockers on zee base.
- 8) Anchor lockers to wall and zee base.
- 9) When anchoring lockers to the wall it is best to anchor to a wall stud or blocking. Also anchor close to a side panel when possible.
- 10) When anchoring to the zee base drill through the bottom of the frame and zee base and use 1-1/4" long nut and bolt.